

REACH

ELECTRIC HEATING, SENSING & CONTROLS

HEATING PRODUCTS



Cert. No.: SG02/00221

E.G.O COMMERCIAL COOKER SELECTOR SWITCHES

Selector switches to control oven functions such as top heat, bottom heat, fan, etc. The switch, temperature control and connectors can be combined as required, which means that function selection and temperature selection can be provided in a single switch. In this case EGO rotary switches are used.

Switch shaft and fixture

Switches are fitted with standard shafts. They are fixed to the appliance with 2 M4 screws (28 mm apart).


Suitable For the following brands cooking range:

EGO, Electrolux, Modular, Bertos, Loipart, Kangli, Samjoo, Inokasn, Olis, Juno, Mareno, MKN, Metos

E.G.O 46 Series



Model: 46.27266.500 (Anti-Clockwise Rotation)
Switch Type: 6 Heat (250V/16A)
Switching Sequence: 0 • 1 • 2 • 3•
Terminal: Quick Tab QC 6.35
Size L X W (mm): 57 X 49
No. of Terminal A Side X B Side: 5 X 3



Model: 46.27266.813 (Anti-Clockwise Rotation)
Switch Type: 6 Heat (250V/16A)
Switching Sequence: 0 • 1 • 2 • 3•
Terminal: Quick Tab QC 6.35
Size L X W (mm): 57 X 49
No. of Terminal A Side X B Side: 5 X 3